



NOTE 1: U.L.S = Upper Limit Switch, used for HOIST applications.

NOTE 2: The P1 & P2 Brake Resistor connections are only present on 7.5hp 460V & 5hp 230V or larger units. External Brake Resistors need to be connected to these terminals for BRIDGE, TROLLEY & some HOIST applications.